

Pinbelegung A1000 und CDTV sowie der Tastaturbuchse am Interface

Keyboard Interface - 6pin MiniDIN

PIN	Signal
1	/DATA
3	GND
4	+V5
5	Clock

Amiga CDTV - 6pin MiniDIN

Pin	Signal
2	/DATA
1	GND
4	+5V
3	Clock

Amiga 1000 - RJ10

Pin	Signal
3	/DATA
4	GND
1	+5V
2	Clock